



# MeacoMist Deluxe Humidifier and Air Purifier Instruction Manual



## **MeacoMist Deluxe Humidifier**

*Please read this instruction manual before using the MeacoMist and keep safe for future reference.*


**Thank you for choosing Meaco, we really appreciate it.**

, 1) 250 \$ & - ( ' 27 < & = & ( % ( = 3 , ( & = ( 67 : \$

---

Maszyny nie wolno używać w pomieszczeniach o następujących warunkach:

- Atmosfera potencjalnie wybuchowa
- Agresywna atmosfera
- Zawiera wysokie stężenie rozpuszczalników
- Niezwykle wysoka zawartość pyłu



*Trzymaj dzieci z dala: Nie pozwalaj dzieciom bawić się urządzeniem lub w jego pobliżu, co może spowodować obrażenia. Upewnij się, że urządzenie jest niedostępne dla dzieci, gdy nie są nadzorowane. To urządzenie nie jest przeznaczone do użytku przez osobę (w tym dzieci) o ograniczonych zdolnościach fizycznych, sensorycznych lub umysłowych lub bez doświadczenia i wiedzy, chyba że otrzymają nadzór lub instrukcje dotyczące korzystania z urządzeń przez osobę odpowiedzialną za ich bezpieczeństwo.*

*Utrzymuj urządzenie w stanie uziemienia: Zawsze używaj urządzenia z uziemioną wtyczką i uziemionym gniazdkiem elektrycznym.*

*Wtyczka z uziemieniem jest podstawową funkcją bezpieczeństwa, która pomaga zmniejszyć ryzyko porażenia lub pożaru. Chroń przewód zasilający przed uszkodzeniem: Nigdy nie używaj urządzenia z uszkodzonym przewodem zasilającym, ponieważ może to spowodować zagrożenie elektryczne lub pożarowe. Jeśli przewód zasilający jest uszkodzony, należy go wymienić na przewód o średnicy ten sam typ i natężenie prądu.*

*Przedłużacze: Przedłużacze muszą być uziemione i być w stanie dostarczać odpowiednie napięcie jednostka.*

*Obchodź się ostrożnie: Nie upuszczaj, nie rzucaj ani nie rozbijaj urządzenia. Nieostrożne traktowanie może uszkodzić elementy lub okablowanie i stwarzać niebezpieczne warunki.*

*Pracuj na stabilnej powierzchni: Zawsze używaj urządzenia na stabilnej, równej powierzchni, na przykład na podłodze lub silny licznik, aby urządzenie nie upadło i nie spowodowało obrażeń  
Chronić przed wodą: Nigdy nie używaj urządzenia w wodzie stojącej lub w kałużach, ponieważ może to stwarzać ryzyko obrażenia od porażenia prądem. Nie przechowywać ani nie używać na zewnątrz.*

*Jeśli okablowanie lub komponenty elektryczne ulegną uszkodzeniu mokre, dokładnie wysusz je przed użyciem urządzenia. W razie wątpliwości nie używaj urządzenia i skonsultuj się z wykwalifikowanym elektrykiem lub inżynierem zatwierdzonego przez Meaco.*

*Utrzymuj wloty powietrza w czystości: Nie zatykań ani nie blokuj wlotów powietrza, umieszczając urządzenie zbyt blisko kurtyń, ściany lub czegośkolwiek, co będzie ograniczać wlot powietrza. Może to spowodować przegrzanie urządzenia i pożar lub zagrożenie porażeniem elektrycznym.*

*Utrzymuj elementy elektryczne w stanie suchym: Nigdy nie pozwól, aby woda dostała się do elementów elektrycznych urządzenia. Jeśli te obszary ulegają zawilgoceniu z jakiegokolwiek powodu, należy je dokładnie wysuszyć przed użyciem urządzenia. W razie wątpliwości nie używaj i skonsultuj się z wykwalifikowanym elektrykiem lub inżynierem zatwierdzonym przez Meaco.*

*Operator musi udostępnić instrukcję obsługi użytkownikowi i upewnić się, że użytkownik rozumie instrukcję.*

## UWAGI OGÓLNE

---

- Przed pierwszym uruchomieniem osuszacza należy uważnie przeczytać instrukcję obsługi .
- Po otrzymaniu osuszacza sprawdź go pod kątem jakichkolwiek uszkodzeń związanych z transportem. W przypadku uszkodzenia należy natychmiast poinformować sprzedawcę oraz firmę transportową w celu spisania protokołu szkody.
- Przechowuj osuszacz i jego opakowanie w bezpiecznym miejscu - jest to niezbędne w przypadku, gdy osuszacz będzie wymagać a serwisu w to przyszłości. Aby oszczędzić nieco miejsca, możesz po prostu przeciąć taśmę zabezpieczającą za pomocą noża, a następnie złożyć pudełko.

## ZASADA DZIAŁANIA NAWILŻACZA

---

Wibracje o dużej prędkości wewnątrz nawilżacza tworzą drobne cząsteczki wody, które są wdmuchiwane do pomieszczenia od góry nawilżacza.


Zalecamy ustawienie nawilżacza tak, aby osiągnąć docelowy poziom od 40% do 60% wilgotności względnej. Pleśń tworzy się przy 68% wilgotności względnej, dlatego ważne jest, aby nie ustawiać zbyt wysokiego poziomu wilgotności RH.

Lampa ultrafioletowa w podstawie nawilżacza po włączeniu zabije bakterie i zarazki, które mogą być obecne w wodzie, aby nawilżona mgła była jak najczystsza. W ramach tego procesu plastik w podstawie odbarwi się i żółknie. Nie jest to usterka i nie można temu zapobiec, jest to dowód, że UV spełnia swoje zadanie. Lampa UV wyłącza się po zdjęciu zbiornika z podstawy. Nigdy nie próbuj patrzeć bezpośrednio na lampę UV, gdy jest używana, ponieważ może to spowodować uszkodzenie wzroku.

To normalne, że nawilżacz ultradźwiękowy tworzy kałużę wody na dowolnej powierzchni, na której stoi. Możesz tego uniknąć lub zmniejszyć, kierując dysze mgły z dala od siebie, aby mgła rozchodziła się w różnych kierunkach i nie skupiała się w całości w jednym obszarze. W razie potrzeby można również zmniejszyć ilość wytwarzanej mgły, aby zmniejszyć ilość wilgoci lądującej przed nawilżaczem.

Można również użyć wentylatora MeacoFan, aby pomóc rozprowadzić mgłę po całym pomieszczeniu. Jeżeli meble, na których ustawiasz nawilżacz są narażone na uszkodzenia spowodowane wilgocią, zalecamy skorzystanie z innego miejsca lub zabezpieczenie powierzchni przed nawilżaczem.

## IDENTYFIKACJA PRODUKTU



- |                         |                      |                            |                             |
|-------------------------|----------------------|----------------------------|-----------------------------|
| 1. Dysza mgiełkowa      | 2. Górna obudowa     | 3. Szczotka do czyszczenia | 4. Uchwyt zbiornika na wodę |
| 5. Zbiornik na wodę     | 6. Okno poziome wody | 7. Korek zbiornika wody    | 8. Obudowa wodna            |
| 9. Panel sterowania     | 10. Wylot powietrza  | 11. Baza                   | 12. HEPA filtr              |
| 13. Pokrywa filtra      | 14. Nóżki            | 15. Pudełko na aromat      | 16. Kabel zasilający        |
| 17. Czujnik wilgotności |                      |                            |                             |



Nóżki




Szczotka do czyszczenia




Pilot

## WIDOK Z LOTU PTAKA PRODUKTU


### GÓRNA OBUDOWA




### ZBIORNIK NA WODĘ



### BAZA




### POD SPODEM



## PANEL STEROWANIA

---



- Gdy pojawi się symbol %, dane na wyświetlaczu cyfrowym będą odnosić się do poziomu wilgotności w otoczeniu.
- Gdy pojawi się symbol ° C, dane na wyświetlaczu cyfrowym będą odnosić się do temperatury otoczenia.
- Gdy pojawi się symbol H, oznacza to, że timer został ustawiony. Naciśnij przycisk Timer, aby zobaczyć liczbę pozostałych godzin.
- Poziom wilgotności w otoczeniu będzie pokazywany przez 10 sekund na wyświetlaczu, a następnie temperatura otoczenia będzie pokazywana przez 5 sekund. To będzie się ciągle powtarzać.



### PRZYCISK ZASILANIA

Kiedy nawilżacz zostanie po raz pierwszy podłączony do sieci, urządzenie wyda sygnał dźwiękowy i włączy się w trybie gotowości. Naciśnij raz przycisk zasilania, wyświetlacz LED zaświeci się i urządzenie zacznie działać. Naciśnij ponownie przycisk zasilania, urządzenie przestanie działać i powróci do trybu gotowości.



### TRYB AUTOMATYCZNY

Naciśnij przycisk Auto / Night, aby przejść do trybu sterowania automatycznego. W tym trybie urządzenie będzie utrzymywać wilgotność względną między 50% a 60%. Urządzenie wybierze najlepszą metodę nawilżania w zależności od poziomu wilgotności otoczenia w pomieszczeniu.



### NIGHT MODE

Przytrzymaj przycisk Auto / Night przez 3 sekundy, aby przejść do trybu nocnego. Światła na wyświetlaczu przygasną. Naciśnij dowolny przycisk, aby zatrzymać tryb nocny, a wyświetlacz rozjaśni się.



## REGULATOR CZASOWY

Naciśnij przycisk timera, aby ustawić wyłącznik czasowy od 1 do 10 godzin. Kontynuuj naciśnięcie przycisku timera, aż do osiągnięcia żądanej liczby godzin, ustawiona liczba mignie trzy razy, a następnie wyświetlacz powróci do temperatury pokojowej. H pojawi się na wyświetlaczu, aby potwierdzić ustawienie timera. Maszyna automatycznie przestanie działać po określonej liczbie godzin. Aby zobaczyć pozostałą liczbę godzin w dowolnym momencie, naciśnij przycisk timera, a liczba pojawi się na wyświetlaczu.



## UV LAMP

Naciśnij przycisk UV / Ioniser, aby włączyć lampę UV. Ta funkcja zabija bakterie w wodzie. Ikona UV pojawi się na wyświetlaczu, aby potwierdzić, że lampa UV jest włączona. Naciśnij ponownie przycisk UV / Ioniser, aby wyłączyć lampę UV. Lampa UV wyłącza się po zdjęciu zbiornika z podstawy. Nigdy nie próbuj patrzeć bezpośrednio na lampę UV, gdy jest używana, ponieważ może to spowodować uszkodzenie wzroku.



## JONIZATOR

Przytrzymaj przycisk UV / jonizator przez 3 sekundy, aby włączyć jonizator. Ta funkcja pochłania cząsteczki kurzu z powietrza. Ikona plus i minus pojawią się na wyświetlaczu, aby potwierdzić, że jonizator jest włączony. Ponownie przytrzymaj przycisk UV / jonizator przez 3 sekundy, aby wyłączyć jonizator.



## CIEPŁA MGŁA

Naciśnij przycisk Warm Mist, aby uruchomić funkcję ciepłej mgiełki. Element PTC w maszynie zacznie działać, a mgła nagrzej się. Na wyświetlaczu pojawią się trzy pionowe linie potwierdzające ustawienie ciepłej mgiełki. Aktywacja ciepłej mgiełki zwiększy wydajność nawilżania. Naciśnij ponownie przycisk Warm Mist, aby zatrzymać tę funkcję. Gdy funkcja ciepłej mgiełki jest wyłączona, urządzenie wydziela chłodną mgiełkę.



## POZIOM MGŁY

Naciśnij przycisk poziomego mgły, aby zmienić wyjściowy poziom nawilżania. Można wybrać poziom wyjściowy 1, 2 lub 3 (poziom 1 jest najniższy, a poziom 3 najwyższy). Trzy poziome kreski po lewej stronie wyświetlacza wskazują, który poziom mgły został wybrany.



## HIGROSTAT

Naciśnij przycisk higrostatu, aby ustawić żądaną docelową wilgotność, ustawiona liczba mignie trzy razy, a następnie wyświetlacz powróci do poziomu wilgotności w otoczeniu. Docelową wilgotność można ustawić w zakresie od 40% do 80% wilgotności względnej. Urządzenie będzie działać do momentu osiągnięcia żądanej docelowej wilgotności. Należy pamiętać, że kiedy urządzenie zacznie działać, będzie nawilżało przez 2 minuty niezależnie od poziomu wilgotności w pomieszczeniu.



## BRAK WODY


Ikona po lewej stronie pojawi się na wyświetlaczu, gdy w zbiorniku nie ma wody. Urządzenie automatycznie przestanie działać.

## SPOSÓB DZIAŁANIA

---

Zobacz strony 5 i 6, aby zidentyfikować każdą część MeacoMist.

1. Przymocuj cztery nóżki do nawilzacza. Niezbędne jest prawidłowe ustawienie nóg, aby podnieść podstawę i umożliwić przepływ powietrza do nawilzacza.
2. Remove the top cover and water tank from the base.



3. Turn the water tank upside down and unscrew the water tank cap removing it from the water tank. The calcium carbonate filter will be attached to the water tank cap.




4. Fill the water tank with water, screw the water tank cap back in place and securely place the water tank back onto the base. The water tank level can be viewed through the window on the left-hand side.



5. Put the top cover back in place.

6. Use the mist nozzles on the top cover to change the direction of mist.
7. Plug the machine into a mains socket and press the Power Button.
8. To use the aroma function, complete the following steps:
  - Remove the aroma box from the machine (see diagram below).
  - Use water-soluble aroma oil to drop into the sponge in the aroma box.
  - Put the aroma box back into the machine.
  - The aroma function will automatically work when the machine is turned on.
  - To stop the aroma function (or when the machine is not in use for a long period of time), remove the sponge from the aroma box and clean it. Re-insert the aroma box into the machine.



9. Choose your desired setting using the control panel (see pages 7 and 8 for more information).
10. Please note the HEPA is already installed in the humidifier. Please see page 12 with instructions on how to change the HEPA filter.


## CLEANING AND STORAGE

---

- Before cleaning the humidifier make sure the power has been turned off and the humidifier is unplugged from the mains.
- Once the humidifier has been used for 50 hours it will automatically stop working as it requires cleaning. The lights on the LED display will blink every two seconds. All the functions set will be saved and the buttons on the display will be disabled.
- The cleaning of the following four components must be carried out: the ultra-sonic pad, the water tank, the inside of the base and the calcium carbonate filter. These should be cleaned as frequently as advised in the instructions below, however they **MUST** be cleaned every 50 hours when the LED lights start to blink.
- Once the cleaning is complete hold the power button down for three seconds. This will reset the accumulator to 0 hours.
- Press the power button again and the humidifier will run as per before.

### ULTRASONIC PAD AND PTC HEATER

- The ultrasonic pad and PTC heater can be located in the base of the humidifier. The ultrasonic pad vibrates at high speed in order to turn water into mist. The PTC heater heats up the water when the warm mist option is chosen.



- In areas where the water quality is hard, limescale will form on the ultrasonic pad and PTC heater surface. The ultrasonic pad and PTC heater will need to be cleaned with a cleaning agent.
- Add a small amount of cleaning agent onto the ultrasonic pad and PTC heater, leave to soak in the sink for 10 to 15 minutes.
- Clean the ultrasonic pad and PTC heater with the small brush provided in the lid of the water tank until the limescale has disappeared.
- Rinse the ultrasonic pad and PTC heater in water to remove any residue.
- Do not clean the ultrasonic pad or PTC heater with metal or any material that could scrape and cause damage.
- The ultrasonic pad and PTC heater must be cleaned weekly.

## **WATER TANK**

- The water tank must be cleaned twice per week when the machine is in frequent use.
- Use a soft cloth to clean the outside of the water tank.
- There may be a small amount of dirt built up on the inside of the water tank – use a soft cloth to clean this.
- If limescale starts to build up inside the water tank, use an appropriate cleaning solution and replace the humidifiers calcium carbonate filter.
- The water tank must be cleaned weekly.

## **INSIDE THE BASE**


- Remove the water from the base and clean away any limescale using the cleaning brush provided.
- Wipe the inside of the base using a damp cloth.
- The inside of the base must be cleaned weekly.
- Please note any yellowing of the plastic is normal and is caused by the UV lamp working correctly.

## **CALCIUM CARBONATE FILTER**

- The calcium carbonate filter can be found inside the water tank attached to the water tank cap.
- To regenerate the calcium carbonate filter, sit the filter in water that is 5% salt for 24 hours. Rinse and insert into the water tank. This should be done every 3 months.
- The calcium carbonate filter needs replacing when white dust deposits start to form around the humidifier. This is limescale.
- When replacing the calcium carbonate filter sit the new filter in water that contains 5% salt for 24 hours. Rinse the filter and insert into the water tank.

## HEPA/CHARCOAL FILTER

- The HEPA filter will be able to retain 97.3% of particles 0.3 micrometres in diameter to help clean your room air.
- The charcoal filter is an active charcoal filter with 12-15g of charcoal to help remove odours.
- The HEPA/charcoal filter can be found underneath the base of the humidifier and must be replaced when the colour changes from white to dark grey – this will roughly be every 6 months.
- To remove the HEPA/charcoal filter press the filter cover open.
- Remove plastic wrapping from the replacement HEPA/charcoal filter before installing.
- The replacement HEPA/charcoal filter must be inserted so the HEPA (white) side is facing outwards. Secure the filter cover back in place.



## SPECIFICATIONS

---

	<b>In Cool Mist Mode</b>	<b>In Warm Mist Mode</b>
<b>Mist Capacity</b>	300ml / hour	400ml / hour
<b>Tank Capacity</b>	5.3 litres	5.3 litres
<b>Power</b>	25W	105W
<b>Noise Level</b>	Maximum 35dB(A)	Maximum 45dB(A)
<b>Aroma Diffuser</b>	Yes	
<b>Ioniser</b>	Yes	
<b>Ultraviolet Water Sterilisation</b>	Yes	
<b>Timer</b>	Yes – between 1 and 10 hours	
<b>Night Mode</b>	Yes	
<b>Adjustable Humidity Level</b>	Yes – between 40%rh and 80%rh	
<b>Auto Shut-Off</b>	Yes	
<b>HEPA Filter</b>	Yes	
<b>Carbon Filter</b>	Yes	
<b>Dimensions (HWD)</b>	335 x 255 x 150 mm	
<b>Nett Weight</b>	2050g	



## TROUBLE SHOOTING

---

TROUBLE	CAUSE	SOLUTION
<b>There is no mist coming out of the humidifier</b>	The machine is not plugged in	Plug the machine in to a mains socket
	The power has not been turned on	Press the Power Button
	There is no water in the water tank	Fill the water tank with water (see page 9)
	There is not enough water in the water tank	Fill the water tank with more water (see page 9)
	The HEPA/charcoal filter is blocked	Replace the HEPA/charcoal filter
<b>There is a strange smell coming from the machine</b>	It is a new machine	Remove the water tank from the base. Place the water tank in a cool and dry place for 12 hours
	The water has been left in the water tank for too long or the water is dirty	Clean the water tank (see page 12) and replace the water
<b>The machine is noisy</b>	The water tank is in the incorrect position	Make sure the water tank is securely in place
	There is not enough water in the water tank	Fill the water tank with more water (see page 9)
	The machine is on an uneven surface	Place the machine on a flat stable surface
	The HEPA/charcoal filter is blocked	Replace the HEPA/charcoal filter
<b>The mist is coming out from the surrounding outlet on the top cover</b>	The lid is not on properly	Attached the lid securely
	The nozzles are blocked by limescale	Clean the steam outlet cap
<b>Yellow staining in base of humidifier</b>	This comes from UV lamp as it sterilises the water	This is not a fault and is a good sign that the UV is working
<b>The display is flashing</b>	The humidifier has reached 50 hours of use and needs cleaning	Clean the humidifier (see page 11)



## WARRANTY AND CUSTOMER SERVICE

---

There is a two-year manufacturer's warranty on your humidifier from the date of purchase. Please register your purchase at <https://meaco.com/warranty-register> - as a thank you, you will be entered into our monthly free prize draw to help support the David Shepard Wildlife Foundation. Registering also allows us to keep you update with any important developments concerning your product.

Within the two-year manufacturer's warranty, all manufacturing defects will be repaired free of charge (excluding damage caused by wear and tear, limescale, mineral deposits or dirt in the water). Filters are not covered under the manufacturer's warranty.

The following applies:

1. Any repairs or replacement of components during the warranty period will not result in an extension of the warranty period.
2. The warranty will expire if any alterations have been made, not genuine components have been fitted or if the humidifier has been repaired by a third party.
3. Components subject to normal wear and tear are not covered by the warranty.
4. The warranty is only valid on presentation of the original, unaltered, and date-stamped purchased receipt.
5. The warranty does not cover damage caused by actions that deviate from those as described in the user's manual or by neglect.
6. The warranty does not cover faults caused by dirt or by third-party products.
7. The warranty does not cover accidental damage.
8. All claims for compensation, including consequential damage, will not be entertained.
9. Using a third-party switching device that turns the humidifier on or off via the mains will invalidate the warranty.

For the full list of the warranty terms and conditions please visit: [www.meaco.com/warranty-terms](http://www.meaco.com/warranty-terms).

To prevent unnecessary expenses, we recommend that you always carefully read the user's manual first. If this does not provide a solution, please call Meaco and we will be happy to help.

*This humidifier has been imported into the UK by:*

*Meaco (UK) Limited  
Meaco House  
Parklands  
Railton Road  
Guildford  
GU2 9JX*

*Telephone: 01483 234900  
Email: [service@meaco.com](mailto:service@meaco.com)  
Website: [www.meaco.com](http://www.meaco.com)*


Please record, for future reference, your date of purchase and where you bought the humidifier from here.

*Date of purchase:* .....

Purchased from [www.meaco.com](http://www.meaco.com) (if not, then please record the supplier's name below).

*Suppliers name:* .....

If your humidifier develops a fault at any time, please contact us and we will always try and help you as best we can. Please keep hold of the original box and packaging your unit arrived in just in case we need to collect the humidifier from you for a repair/service in the future.



This marking indicates that this product should not be disposed with other household wastes throughout the UK and EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

